

## Variable width Variable width Right-of-way Right-of-way witness post witness post Set R/W monuments 5, Set R/W monuments flush to existing ground flush to existing ground 5 6 1075.00 25 1075 Stamp station, offset and PLS information into cap TYPICAL SECTION 30 ft LT **RIGHT-OF-WAY MONUMENTATION**

## NOTE:


- 1. Right-of-Way Witness Post:
  Set a 6 foot long flexible plastic post. Right-of-Way
  witness posts should be brown, green or other suitable colors
  to match surroundings. Attach a "Survey Marker Witness"
  plaque to the post. Station, offset and PLS date of survey
  should be permanently attached to the front of the post facing
  the designed alignment.
- 2. Witness post to be used when Right-of-Way witness post assembly is required.
- 3. Set monuments using a professional land surveyor according to the requirements of the state code.
- 4. Station and distances based on Right-of-Way centerline.
- 5. Install markers so that the center of the cap is not more than ½" from the point established.



RIGHT-OF-WAY WITNESS POST ASSEMBLY DETAIL



RIGHT-OF-WAY MONUMENT AND WITNESS POST EARTH INSTALLATION



CAP DETAIL

RIGHT-OF-WAY MONUMENT AND WITNESS POST SOLID ROCK INSTALLATION

NO SCALE

U.S. DEPARTMENT OF TRANSPORTATION FEDERAL HIGHWAY ADMINISTRATION OFFICE OF FEDERAL LANDS HIGHWAY

WFLHD DETAIL


## RIGHT-OF-WAY MONUMENTATION

DETAIL APPROVED FOR USE 5/2003

REVISED: 12/2006 11/2007 11/2014

USE 5/2003 DETAIL W621-1

PROJECT NUMBE




## NOTE:

CAP DETAIL

AND WITNESS POST

SOLID ROCK INSTALLATION

- 1. Right-of-Way Witness Post: Set a 1830 mm long flexible plastic post. Right-of-Way witness posts should be brown, green or other suitable colors to match surroundings. Attach a "Survey Marker Witness" plaque to the post. Station, offset and PLS date of survey should be permanently attached to the front of the post facing the designed alignment.
- 2. Witness post to be used when Right-of-Way witness post assembly is required.
- 3. Set monuments using a professional land surveyor according to the requirements of the state code.
- 4. Station and distances based on Right-of-Way centerline.
- 5. Install markers so that the center of the cap is not more than 13 mm from the point established.
- 6. Dimensions without units are millimeters.



AND WITNESS POST

**EARTH INSTALLATION** 

ASSEMBLY DETAIL

U.S. DEPARTMENT OF TRANSPORTATION FEDERAL HIGHWAY ADMINISTRATION OFFICE OF FEDERAL LANDS HIGHWAY

WFLHD METRIC DETAIL

**RIGHT-OF-WAY MONUMENTATION** 

NO SCALE REVISED: 12/2006 11/2007 11/2014

DETAIL APPROVED FOR USE 5/2003 DETAIL WM621-1