

## NOTE:

1. Place delineators nearly opposite each other on horizontal curves.

2. Install all delineators with reflectors facing adjacent oncoming traffic.

3. Install delineators behind the rail at guardrail locations.

4. Offset delineators a minimum distance of 4 feet in areas of heavy snow removal operations.

5. On roads with less than 500 ADT, use delineators only for situations such as sharp vertical or horizontal curves, or other undesirable geometrics exist.

6. Vary the post spacing up to ¼ of the spacing shown to clear driveways, cross roads, intersections or ramps. Eliminate the post if the variation is exceeded.

7. When the contract does not provide for the construction of the ultimate pavement, allow for the thickness of base and pavement to be placed later when establishing the elevation of the traffic delineators.

8. If horizontal and vertical curves are combined, use the more restrictive spacing.

9. Measure spacing along the shoulder or face of curb.

REFLECTOR DETAILS					
′ΡE	REFLECTOR & TARGET/ POST COLOR	NUMBER OF REFLECTORS	USAGE AND SPACING		
/-1	White	1	Max. tangent spacing: 400' each side		
			Intersections (tapers and widening): 100'		
			<i>See Horizontal Curves table for variations</i>		
/-2	White	2 Intersection Radiu 3 min. @ 50'			
			Lane Reduction: 3 min @ 100'		

	U.S. DEPARTMENT OF TRANSPORTATION FEDERAL HIGHWAY ADMINISTRATION OFFICE OF FEDERAL LANDS HIGHWAY				
	WFLHD DETAIL				
	OREGON				
DELINEATORS					
	DETAIL APPROVED FOR USE 11/2014	DETAIL			
	REVISED:	W633-70			

NO SCALE