

Workflow 1: Manually attaching the CFLHD DGN Library



Workflow 1 - Manually attaching the CFLHD dgn library is for information only. CFLHD designers should not manually attach or edit configuration variables. For CFLHD, the CADD Coordinator sets the configuration variables.

1. *Select Workspace>Configuration from the main MicroStation pull down menus*




Figure 5-1: Workspace Menu

2. *In the Workspace configuration list, select MS_DGNLIBLIST*




Figure 5-2: DGNLIBLIST Configuration Variable

3. Choose the select button, and path to the location of the DGN Library.
Note the two locations for FLH and CFL (.dgnlibs) are:

...:\V8i_resource\CFL_Local\MicroStation\Library_Files, and

...:\V8i_resource\FLH_Common\MicroStation\Library_Files




Figure 5-3: Select File for DGN Library List

4. Select the library and click the Add button to add the file to the File List section in the bottom of the dialog box.
5. Select the Done button, and then select OK back on the Configuration dialog.
6. When prompted to save changes to workspace, select Yes.




Figure 5-4: MicroStation Alert Dialog

7. In order for these changes to take affect you must exit MicroStation and restart.