

Workflow 2: Setting the Annotation Scale in the Model Properties

1. From the MicroStation Primary Tools toolbar, select the Models icon.




Figure 5-1: Primary Tools

2. From the Models dialog box, select Edit Model Properties.




Figure 5-8: Models Dialog

3. Select the Edit Model Properties Icon.

You can rename the model, give a new description, select the annotation scale, set a Global Line Style Scale, and set whether or not the model can be placed as a cell.

In the example below, the annotation scale has been set to 1"=100'. Once the model properties have been set, select OK.




Figure 5-9: Model Properties – Set a model’s Annotation Scale