

Workflow 1: Attaching CFLHD Cell Libraries

1. Download [V8i_resource.zip](#) from the CFLHD web site.
 - Cell libraries are now separated as *FLH_Common* and *CFL_Local* files. The paths to the library locations are set within the Project Configuration Files (.pcf). The user should leave the libraries located at:
V8i_resource\CFL_Local\MicroStation\Cell_Lib, and
V8i_resource\FLH_Common\MicroStation\Cell_Lib




Figure 8.1-1: Cell Library Path(s) Variable

2. From the MicroStation drop down menu, select *Element>Cells*.




Figure 8.1-2: Element Menu

- The cell library palette will now be accessible. Select File>Attach, and navigate to the correct cell library. The list of available libraries, though the set variable paths will be shown below.




Figure 8.1-3: Cell Library Dialog Box

- Once selected, the cells will be visible in the windows on the Cell Library palette.




Figure 8.1-4: Populated Cell Library Dialog Box



For CFLHD employees, cell libraries are automatically attached while opening a design file using the Project Configuration (*.pcf). Contact CADD support to get properly setup if the correct cell libraries are not displaying.