

Workflow 1: Attaching a level library

1. Open the Level Manager by selecting the icon in the Primary Tools tool bar, or by selecting Settings>Level>Manager.




Figure 9-1: Accessing Level Manager




Figure 9-2: Accessing Level Manager

2. Notice the dialog that is activated has only one level shown, Default. These are also no level filters available.




Figure 9-3: Level Manager

3. *Select Levels>Library>Attach.*




Figure 9-4: Attaching DGN Library

4. *Browse to the file FLH_Combined.dgnlib, select OK. The Library Files are located in the:*
V8i_resource\FLH_Common\MicroStation\Library_Files\directory.




Figure 9-5: Level Manager with DGN Library Attached