



NOTE:

1. Use straw bales in drainage ditches only for low flow conditions and when specified on the Erosion Control Plans.
2. Dimensions without units are millimeters.




ELEVATION




PLAN


INSTALLATION OF A STRAW BALE BARRIER AT TOE OF FILL




Step 1: Excavate trench



Step 3: Tightly pack straw between bales (plan view of bales)




Step 2: Install bales




Step 4: Backfill soil against bales

PROPERLY STAKED AND ENTRENCHED STRAW BALES



ELEVATION



PLAN

INSTALLATION OF A STRAW BALE BARRIER IN DITCH

See Note 1

NO SCALE

U.S. DEPARTMENT OF TRANSPORTATION FEDERAL HIGHWAY ADMINISTRATION OFFICE OF FEDERAL LANDS HIGHWAY	
METRIC FLH STANDARD	
STRAW BALES	
STANDARD APPROVED FOR USE 3/1996 REVISED: 6/2005 6/2007	STANDARD M157-3