r								
LENGTH AND SPACING TABLE								
		BUFFER	CHANNELIZING DEVICE					
APPROACH SPEED*	MINIMUM TAPER LENGTH**	SPACE	TAPER	BUFFER	WORK			
51 220		LENGTH	AREA	SPACE	SPACE			
MPH	FEET	FEET	SPACING IN FEET					
20	Shoulder taper formula:	115	20	40	40			
25	$L = \frac{WS^2}{1000000000000000000000000000000000000$	155	25	50	50			
30		200	30	60	60			
35	$L = \frac{WS}{2}$ for $S \ge 45$ MPH	250	35	70	70			
40		305	40	80	80			
45	Where:	360	45	90	90			
50	<i>L</i> = <i>Minimum length of taper</i>	425	50	100	100			
55	W = Width of offset in feet	495	55	110	110			
60	S = Numerical value of posted speed	570	60	120	120			
65	limit or 85 percentile speed prior	645	65	130	130			
70	to work in miles per hour	730	70	140	140			

SIGN SPACING TABLE					
ROAD TYPE	DISTANCE BETWEEN SIGNS IN FEET				
		В	С		
Urban and Rural 30 MPH and less	100	100	100		
Urban and Rural 35 MPH to 50 MPH		350	350		
Rural greater than 50 MPH	500	500	500		
Expressway / Freeway		1500	2640		

at required spacing.

